

Elesa 10 運指表

The notes are written according to general saxophone notation, but if the transpose set to 0 (C), the actual pitch of the Eb or Bb tube and the actual pitch of the Elesa will be different. If you want to match the actual sound of a general saxophone, use the transpose function and set it to +3 (Eb) or -2 (Bb).

Note: Depending on the tone, such as Soprano sax or Baritone S, the sound may be 1~2 octaves higher or lower.

表記されている音符は、一般的なサキソフォンの記譜に合わせて表記していますが、トランスポーズが 0 (C) に設定されている場合は、Eb 管や Bb 管の実音と Elesa の実音程が異なります。一般的なサキソフォンの実音と合わせたい場合は、適宜トランスポーズ機能を使用して、+3 (Eb) または -2 (Bb) に設定してお使いください。

なお、Soprano Sax や Baritone Sax など、音色によって 1~2 オクターブ上、または下の音が出る場合があります。

SAXタイプ																					
リコーダータイプ Recorder																					
ウインドシンセ タイプ Wind Synth																					

Elesa 10 運指表

The notes are written according to general saxophone notation, but if the transpose set to 0 (C), the actual pitch of the Eb or Bb tube and the actual pitch of the Elesa will be different. If you want to match the actual sound of a general saxophone, use the transpose function and set it to +3 (Eb) or -2 (Bb).

Note: Depending on the tone, such as Sopranoax or Baritone S, the sound may be 1~2 octaves higher or lower.

表記されている音符は、一般的なサキソフォンの記譜に合わせて表記していますが、トランスポーズが0 (C) に設定されている場合は、Eb 管や Bb 管の実音と Elesa の実音程が異なります。一般的なサキソフォンの実音と合わせたい場合は、適宜トランスポーズ機能を使用して、+3 (Eb) または -2 (Bb) に設定してお使いください。

なお、Soprano Sax や Baritone Sax など、音色によって 1~2 オクターブ上、または下の音が出る場合があります。

Trumpet タイプ																							

Left ハンド タイプ Left Hand																							
Right ハンド タイプ Right Hand																							